



Tools & Supplies Needed

- Band Saw or Coping Saw
- Electric hand drill or press
- 3/8" Drill Bit for weight holes
- #44 Drill Bit for axle holes
- Sharp Pointed Object (punch)
- 3/8" Tungsten Cylinders or...
- 3/8" Lead wire for weight
- Body Putty / Wood Filler
- Safety Glasses
- Hearing Protection
- Scissors
- Markers
- Sandpaper
- Paint, Accessories and Decals

Extende Axle Holes/Slots - Blue

Standard BSA Axle Holes/Slots - Red

1"

1 5/8"

TURBO COP CAR

5/8"

5/8"

Front View

TOP

Derby Monkey Garage

SIDE

3/8" HOLES FOR WEIGHTS

AXLE LINE

TO SCALE: 1 SQUARE = 1/4"

AXLE LINE

WWW.DERBYMONKEY.COM

RECOMMENDED ACCESSORIES:

Police Car Decals – CLICK HERE

Monkey Dust Graphite – CLICK HERE

Police Light Bar – CLICH HERE

Testors One-Coat Spray Paint – CLICK HERE

Pinewood Derby Wheels – CLIC HERE

Pro Axle Guide – CLICK HERE